


ENCLAVE® PANEL MOUNTING OPTIONS

Top Mount (TM)



- Use for permanent mounting
- Install anywhere on the desk
- Work on all thickness tops
- Clamp position on panel is adjustable
- Kits include 2 or 3 Top Mounts depending on the width of the desk divider



Top Mount (STM)



Top Mount (BTM)

Tower Adhesive Mount (STW.R)




- For use with Clear & Frosted Acrylic
- Adhesive is used to attach metal plate to work surface
- Aluminum cover snaps into metal plate and Tower Mount is screwed into cover
- Clamp position on panel is adjustable
- Kits include 2 or 3 Tower Mounts depending on width of panel



Tower Adhesive Mount (STW.R)

Edge Clamp - Knob (CEK)



- Fast & easy installation and relocation
- Mount along the edge of work surface
- Clamp fits 3/4" to 2" thick tops
- No screwing or drilling into work surface required
- Clamp position on panel is adjustable
- Kits include 2 or 3 Clamps depending on the width of the desk divider



Edge Clamp - Knob (SCEK)



Edge Clamp - Knob (BCEK)


Edge Clamp - Gap Knob (CEKG)



- Extension clamp mount to allow for cable management of worksurface mounted accessories
- Clamp mounts back panel 1" off worksurface
- Gap plate and panel extend 2.5" off worksurface when fully assembled
- For use on 42" W and wider Enclave panels
- Knob clamp fits 3/4" to 2" thick worksurface tops
- No screwing or drilling into worksurface required
- Clamp position on panel is adjustable
- Kits include 2 or 3 Clamps depending on the width of the desk divider



Edge Clamp - Gap Knob (SCEKG)



Edge Clamp - Lever (CEL)

- Patented Lever allows for easy installation with no low hanging knob
- Fast & easy installation and relocation
- Mount along the edge of work surface
- Clamp fits 5/8" to 1.5" thick tops
- No screwing or drilling into work surface required
- Clamp position on panel is adjustable
- Kits include 2 or 3 Clamps depending on the width of the desk divider


**Patented*



Edge Clamp - Lever (SCEL)



Edge Clamp - Lever (BCEL)




Edge Clamp - Hex (CEH) (Low Profile)

- Fast & easy installation and relocation
- Mount along the edge of work surface
- Clamp fits 1.1" to 1.22" thick tops
- No screwing or drilling into work surface required
- Clamp position on panel is adjustable
- Kits include 2 or 3 clamps depending on the width of the desk divider
- Use when minimum free space is available on underside of work surface



Edge Clamp - Hex (SCEH)



Middle Clamp - Single (CMS)

- Patented Lever allows for easy installation with no low hanging knob
- Fast & easy installation and relocation
- Mount perpendicular to edge of work surface
- Clamp fits 5/8" to 1.5" thick tops
- No screwing or drilling into work surface required
- Only one clamp required to secure a desk divider
- Kits include 1 middle clamp and one metal resting plate

**Patented*



Middle Clamp - Single (SCMS)



Middle Clamp - Double (CMD)

- Patented Lever allows for easy installation with no low hanging knob
- Fast & easy installation and relocation
- Mount perpendicular to edge of work surface
- Clamp fits 5/8" to 1.5" thick tops
- No screwing or drilling into work surface required
- Kit includes 2 Middle Clamps
- A central metal resting plate will be included with panels 54" and wider for a total of 3 clamps

**Patented*



Middle Clamp - Double (SCMD)




Middle Clamp - Knob (CMKS)

- Fast & easy installation and relocation
- Mount perpendicular to edge of worksurface
- Clamp fits 1.1" to 1.22" thick tops
- No screwing or drilling into work surface
- Only one clamp required to secure panel to work surface
- Kit includes 1 middle clamp with knob and one or two metal resting plates depending on width of panel



Middle Clamp - Knob (CMKS)



Free Standing Foot (FS)

- Fast & easy installation and relocation
- Stands freely on top of worksurface
- Clamp position on panel is adjustable
- No screwing or drilling into worksurface required
- A center Pad will be included on units 54" and wider



Free Standing (SFS)



Bench Mount (BM)

- Use for permanent mounting
- Fits between back to back workstations with a minimum gap of 2.25"
- Clamp position on panel is adjustable
- Can be used on all thickness tops
- Kit includes 2 to 3 Bench Mounts depending on width of the panel



Bench Mount (SBM)



Invisible Mount (IM)

- For use with 3/4" (18mm) acoustic EchoScape™ only
- Permanent mount - Screw down
- Mounting locations on EchoScape™ panel are preset and posts slide into panel for invisible Mount
- Kits include 2 or 3 Invisible Mounts depending on width of panel



Invisible Mount (IM)



Invisible Adhesive Mount (SIM.R)

- For use with 3/4" (18mm) acoustic EchoScape™ only
- Adhesive is used to attach metal plate to top cap
- Aluminum cover snaps into metal plate and Invisible Mount is screwed into cover
- Mounting locations on EchoScape™ panel are preset and posts slide into panel for invisible mount
- Kits include 2 or 3 Invisible Mounts depending on width of panel



Invisible Adhesive Mount (SIM.R)



Invisible Edge Clamp - Knob (ICEK)


- For use with 3/4" (18mm) acoustic EchoScape™ only
- Mounting locations on EchoScape™ panel are preset and posts slide into panel for Invisible Mount
- Clamp fits 3/4" to 2" thick tops
- No screwing or drilling into work surface required
- Kits include 2 or 3 Clamps depending on the width of the desk divider



Invisible Edge Clamp - Knob (ICEK)



Invisible Edge Clamp - Knob (BICEK)



Invisible Edge Clamp - Gap Knob (ICEKG)

- For use with 3/4" (18mm) acoustic EchoScape™ only
- Mounting locations on EchoScape™ panel are preset and posts slide into panel for Invisible Mount
- For use on 42" W and wider Enclave panels
- Extension clamp mount to allow for cable management of worksurface mounted accessories
- Clamp mounts back panel 1" off worksurface
- Gap plate and panel extend 2.5" off worksurface when fully assembled
- Knob clamp fits 3/4" to 2" thick worksurface tops
- No screwing or drilling into worksurface required
- Kits include 2 or 3 Clamps depending on the width of the desk divider



Invisible Edge Clamp - Gap Knob (ICEKG)



Invisible Edge Clamp - Lever (ICEL)

- For use with 3/4" (18mm) acoustic EchoScape™ only
- Mounting locations on EchoScape™ panel are preset and posts slide into panel for Invisible Mount
- Clamp fits 5/8" to 1.5" thick tops
- Patented Lever allows for easy installation with no low hanging knob
- No screwing or drilling into work surface required
- Kits include 2 or 3 Clamps depending on the width of the desk divider



Invisible Edge Clamp - Lever
(SICEL)



Invisible Edge Clamp - Lever
(BICEK)



Invisible Middle Clamp Single (ICMS)

- For use with 3/4" (18mm) acoustic EchoScape™ only
- Mounting locations on EchoScape™ panel are preset and posts slide into panel for Invisible Mount
- Mount perpendicular to edge of work surface
- Clamp fits 5/8" to 1.5" thick tops
- Patented Lever allows for easy installation with no low hanging knob and relocation
- No screwing or drilling into work surface required
- Only one clamp required to secure a desk divider
- Kits include 1 middle clamp and one metal resting plate



Invisible Middle Clamp Single
(SICMS)



Invisible Free Standing Foot (IFS)

- For use with 3/4" (18mm) acoustic EchoScape™ only
- Mounting locations on EchoScape™ panel are preset and posts slide into panel for Invisible Mount
- Stands freely on top of worksurface
- No screwing or drilling into worksurface required
- A center metal resting plate will be included on units 54" and wider



Invisible Free Standing Foot
(SIFS)