



## Material Cleaning and Disinfecting Instructions

Below are the recommended cleaning and disinfecting procedures for each of our materials.

### Frosted and Clear Acrylic

Our Frosted and Clear Acrylic can be safely cleaned and disinfected with non-abrasive acrylic cleaners that do not contain ammonia:

#### Clean

- Novus® No. 1 - Plastic Clean & Shine
- Brilliance® Acrylic Cleaner
- Mild soap and water solution – 1 tsp of soap per quart of water

#### Disinfect

- 1/3 cup bleach per gallon of water OR
- 4 teaspoons bleach per quart of water

**When cleaning Frosted and Clear Acrylic, always be sure to use a soft, non-abrasive cloth, such as a microfiber or lint free cloth, and apply light pressure only. Never use paper towels as it will scratch the Acrylic.**

### Whiteboards and Glass Boards

#### TruBrite Whiteboards

Our TruBrite whiteboards can be safely cleaned and disinfected with:

#### Clean and Disinfect

- Mild soap and water
- Dry erase board cleaner

#### Glass Boards

Our Glass Boards can be safely cleaned and disinfected with:

#### Clean

- Mild soap and water
- Glass Cleaner
- Ammonia Solution (1/2 cup ammonia per gallon of water)



### Disinfect

- Isopropyl alcohol
- Bleach Solution (2.5 tbsp bleach per gallon of water)

**When cleaning Whiteboards and Glass boards, always be sure to use a soft, non-abrasive cloth, such as a microfiber or lint free cloth, and apply light pressure only.**

### Fabrics

Our Fabrics can be safely cleaned and disinfected with:

#### Clean

- Water-based foam or upholstery cleaner or dry-cleaning solvents

#### Disinfect

- Disinfectant sprays

**When cleaning Fabrics it is recommended to vacuum the material first. Never saturate Fabrics with liquids as it may cause a water ring. Always be sure to test cleaning solutions in a small, inconspicuous area first.**

### EchoScape™

Our EchoScape™ panels are made with compressed colored polyester fibers, therefore the colors do not fade or run. EchoScape™ can be safely cleaned and disinfected with the following solutions and using a spray bottle for application, do not oversoak:

#### Clean

- Equal parts soap and warm (**NOT** hot) water
  - For tougher stains, blot the affected area with a soft, white, lint-free cloth
- Fabric or carpet cleaners

#### Disinfect

- 75% alcohol spray

**When cleaning EchoScape™ always be sure to test it on a small inconspicuous area first. Vacuum EchoScape™ material before cleaning to remove loose dirt and dust. Avoid using abrasive cleaners and cleaners containing ketones, kerosene, and petroleum products.**



## Laminate

Our Laminate can be safely cleaned and disinfected with:

### Clean

- Multi-Surface Cleaners
- Mild Soaps

### Disinfect

- Disinfecting wipes
- Disinfectant sprays
- Bleach Solution (10% bleach and 90% water)

**When cleaning Laminate, always be sure to use a soft, non-abrasive cloth, such as a microfiber or lint free cloth, and apply light pressure only. Rinse with clean water using a clean, non-abrasive cloth. Do not flood the laminate, especially near seams, since water can penetrate and cause the substrate to swell. Dry the surface with a clean, non-abrasive cloth.**

## Aluminum Frames

Our Aluminum Frames can be safely cleaned and disinfected with:

### Clean

- Mild soap and water

### Disinfect

- Bleach solution (1 tbsp bleach per gallon of water)

**When cleaning Aluminum Frames it is recommended to use a soft, non-abrasive cloth, such as a microfiber or lint free cloth, and apply light pressure only.**